

INDOOR AIR QUALITY SENSOR



THERMEX[®] SENSEMEX

INDOOR AIR QUALITY SENSOR

Thermex Sensemex indoor air quality sensor for Thermex hood or Thermex Ventmex. The sensor measures the air quality and automatically adjusts the ventilation.



VOC



HUMIDITY



SLEEP (8 h)




BOOST (15 min.)



1



AA - 1,5 V



2x AA






 = 10 min. calibration mode




10 min.

2



2b



min. 1 meter



THERMEX[®] SENSEMEX



QUICKGUIDE

536.99.5052.9

THERMEX SCANDINAVIA A/S

www.thermex.dk

info@thermex.dk



OTHER THERMEX® HOOD PAIRING OPTIONS:

